
ABSTRACT

Available bit rate (ABR) service has been developed to support data applications over asynchronous transfer mode (ATM) networks. The network continuously monitors its traffic and provides feedback to the source end systems. This article explains the rules that the sources have to follow to achieve a fair and efficient allocation of network resources.

Source Behavior for ATM ABR Traffic Management: An Explanation

Raj Jain, Shivkumar Kalyanaraman, Sonia Fahmy, and Rohit Goyal, The Ohio State University

Seong-Cheol Kim, Samsung Electronics Co. Ltd.

The traffic management specification TM4.0 developed by the ATM Forum is a great technological development [1, 2]. From May 1993 to April 1996, it took approximately three years to develop. Each bimonthly meeting of the working group was attended by over 150 persons. The effort has resulted in significant advances in effective traffic management in networks covering large distances, with a large number of flows and having a variety of quality of service (QoS) requirements.

A key distinguishing feature of ATM networks as compared to current packet networks is that they offer multiple qualities of service (QoS). TM4.0 specifies five classes of service: constant bit rate (CBR), real-time variable bit rate (rt-VBR), non-real-time variable bit rate (nrt-VBR), available bit rate (ABR), and unspecified bit rate (UBR). Of these, the ABR service has been specifically designed for efficient handling of data traffic.

One of the challenges in designing ATM traffic management was to maintain the QoS for various classes while attempting to make maximal use of network resources. This is what distinguishes traffic management from the "congestion control" problem of the past. Congestion control deals only with the problem of reducing load during overload. Traffic management deals not only with load reduction under overload or load increase during underload but, more important, tries to ensure that the QoS guarantees are met in spite of varying load conditions. Thus, traffic management is required even if the network is underloaded. This article provides insights into the development of ABR traffic management and explains the reasons behind various decisions. The basic model used is introduced in the next section.

ABR RATE-BASED TRAFFIC MANAGEMENT MODEL

ABR mechanisms allow the network to divide the available bandwidth fairly and efficiently among the active traffic sources. In the ABR traffic management framework, the *source end systems* limit their data transmission to rates allowed by the network. The network consists of *switches* which use their current load information to calculate the

allowable rates for the sources. These rates are sent to the sources as feedback via resource management (RM) cells. RM cells are generated by the sources and travel along the data path to the *destination end systems*. The destinations simply return the RM cells to the sources. The components of the ABR traffic management framework are shown in Fig. 1. In this tutorial, we explain the source and destination end-system behaviors and their implications for ABR traffic management.

The ABR traffic management model is called a "rate-based end-to-end closed-loop" model. The model is rate-based because the sources send data at a specified rate. This is different from current packet networks (e.g., Transmission Control Protocol — TCP), where the control is "window-based" and the sources limit their transmission to a particular number of packets. The ABR model is closed-loop because there is a continuous feedback of control information between the network and the source. If more sources become active, the rate allocated to each source is reduced. The model used for CBR and VBR traffic, on the other hand, is "open-loop" in the sense that rates are negotiated at the beginning of the connection and do not change dynamically. Finally, the model is end-to-end because the control cells travel from the source to the destination and back to the source. The alternative of "hop-by-hop" control, in which each switch would give feedback to the previous switch, was considered and not accepted due to its complexity. However, one can achieve the hop-by-hop control in TM4.0 using the virtual source/virtual destination (VS/VD) feature discussed later in this section.

When there is a steady flow of RM cells in the forward and reverse directions, there is a steady flow of feedback from the network. In this state, the ABR control loop has been established and the source rates are primarily controlled by the network feedback (closed loop control). However, until the first RM cell returns, the source rate is controlled by the negotiated parameters, which may or may not relate to the current load on the network. The virtual circuit (VC) is said to be following an open-loop control during this phase. This phase normally lasts for one round-trip time (RTT). As explained later, ABR sources are required to return to the open-loop control after long idle intervals. Traffic sources that have active periods (bursts) when data is transmitted at the allocated rate and idle periods when no data is transmitted

are called “bursty sources” Open-loop control has a significant influence on the performance of bursty traffic, particularly if it consists of bursts separated by long idle intervals.

There are three ways for switches to give feedback to the sources. First, each cell header contains an explicit forward congestion indication (EFCI) bit, which can be set by a congested switch. This mechanism is a modification of the DECbit scheme [3]. Such switches are called “binary” or “EFCI” switches. Second, RM cells have two bits in their payload, the congestion indication (CI) bit and the no increase (NI) bit, which can be set by congested switches. Switches that use only this mechanism are called “relative rate marking switches.” Third, the RM cells also have another field in their payload, explicit rate (ER), which can be reduced by congested switches to any desired value. Such switches are called “explicit rate switches.”

Explicit rate switches normally wait for the arrival of an RM cell to give feedback to a source. However, under extreme congestion they are allowed to generate an RM cell and send it immediately to the source. This optional mechanism is called backward explicit congestion notification (BECN).


Switches can use the VS/VD feature to segment the ABR control loop into smaller loops. In a VS/VD network, the switches additionally behave as both a (virtual) destination end system and a (virtual) source end system. As a destination end system, it turns around the RM cells to the sources from one segment. As a source end system, it generates RM cells for the next segment. This feature can allow feedback from nearby switches to reach sources faster, and allow hop-by-hop control, discussed earlier.

ABR PARAMETERS

At the time of connection setup, ABR sources negotiate several operating parameters with the network. The first among these is the peak cell rate (PCR). This is the maximum rate at which the source will be allowed to transmit on this VC. The source can also request a minimum cell rate (MCR), which is the guaranteed minimum rate. The network has to reserve this bandwidth for the VC. During the data transmission stage, the rate at which a source is allowed to send at any particular instant is called the “allowed cell rate” (ACR). The ACR is dynamically changed between the MCR and PCR. At the beginning of the connection and after long idle intervals, the ACR is set to the initial cell rate (ICR). During the development of the RM specification, all numerical values in the specification were replaced by mnemonics. For example, instead of saying “every 32nd cell should be an RM cell” the specification states “every N_{rm} th cell should be an RM cell.” Here, N_{rm} is a parameter whose default value is 32. Some of the parameters are fixed, while others are negotiated. This being a tutorial (and not a standard document), we have reverted back to the default values of these parameters, which makes it easier to understand. A complete list of parameters used in the ABR mechanism is presented in Table 1. The parameters are explained as they occur in our discussion.

IN-RATE AND OUT-OF-RATE RM CELLS

Most resource management cells generated by the sources are counted as part of their network load in the sense that the total rate of data and RM cells should not exceed the ACR of the source. Such RM cells are called “in-rate” RM cells. Under exceptional circumstances, switches, destinations, or even sources can generate extra RM cells. These “out-of-rate” RM cells are not counted in the ACR of the source and are distinguished by having their cell loss priority (CLP) bit



■ Figure 1. ABR traffic management model: source, switch, destination, and resource management cells.

set, which means that the network will carry them only if there is plenty of bandwidth and can discard them if congested. The out-of-rate RM cells generated by the source and switch are limited to 10 RM cells per second per VC. One use of out-of-rate RM cells is for BECN from the switches. Another use is for a source, whose ACR has been set to zero by the network, to periodically sense the state of the network. Out-of-rate RM cells are also used by destinations of VCs whose reverse direction ACR is either zero or not sufficient to return all RM cells received in the forward direction.


Note that the in-rate and out-of-rate distinction applies only to RM cells. All data cells in ABR should have CLP set to 0 and must always be within the rate allowed by the network.

FORWARD AND BACKWARD RM CELLS

RM cells traveling from the source to the destination are called “forward RM” (FRM) cells. The destination turns around these RM cells and sends them back to the source on the same VC. Such RM cells traveling from the destination to the source are called “backward RM” (BRM) cells. FRM and BRM cells are illustrated in Fig. 2. Note that when there is bidirectional traffic, there are FRMs and BRMs in both directions on the VC. A bit in the RM cell payload indicates whether it is an FRM or BRM. This direction bit (DIR) is changed from 0 to 1 by the destination.

Label	Expansion	Default value
PCR	Peak cell rate	-
MCR	Minimum cell rate	0
ACR	Allowed cell rate	-
ICR	Initial cell rate	PCR
TCR	Tagged cell rate	10 cells/s
N_{rm}	Number of cells between FRM cells	32
M_{rm}	Controls bandwidth allocation between FRM, BRM, and data cells	2
T_{rm}	Upper bound on inter-FRM time	100 ms
RIF	Rate increase factor	1/16
RDF	Rate decrease factor	1/16
ADTF	ACR decrease time factor	0.5 ms
TBE	Transient buffer exposure	16,777,215
CRM	Missing RM-cell count	$\lceil TBE/N_{rm} \rceil$
CDF	Cutoff decrease factor	1/16
FRTT	Fixed round-trip time	-

■ Table 1. List of ABR parameters.



■ **Figure 2.** Forward and backward resource management cells (FRMs and BRMs).

RM CELL FORMAT

The complete format of the RM cells is shown in Fig. 3. Every RM cell has the regular ATM header of five bytes. The payload type indicator (PTI) field is set to 110 (binary) to indicate that the cell is an RM cell. The protocol id field, which is one byte long, is set to one for ABR connections. The direction (DIR) bit distinguishes forward and backward RM cells. The backward notification (BN) bit is set only in switch generated BECN cells. The congestion indication (CI) bit is used by relative rate marking switches. It may also be used by explicit rate switches under extreme congestion, as discussed later. The NI bit is another bit available to explicit rate switches to indicate moderate congestion. The request/acknowledge, queue length, and sequence number fields of the RM cells are for compatibility with International Telecommunications Union — Telecommunications Standards Sector (ITU-T) Recommendation I.371, and are not used by the ATM Forum. The current cell rate (CCR) field is used by the source to indicate to the network its current rate. Some switches may use the CCR field to determine a VC's next allocation, while others may measure the VC's rate and not trust CCR. The MCR field is redundant in the sense that, like PCR, ICR, and other parameters, it does not change during the life of a connection. However, its presence in the RM cells reduces the number of lookups required in the switch.

The ER, CI, and NI fields are used by the network to give feedback to the sources. The ER field indicates the maximum rate allowed to the source. When there are multiple switches

ATM header	5 bytes	
Protocol ID	1 bytes	1=AR
Direction	1 bit	0=Forward
Backward notification	1 bit	1=Switch/dest gene
Congestion indication	1 bit	1=High congestion
No increase	1 bit	1=Mild congestion
Request/acknowledge*	1 bit	
Reserved	3 bits	
Explicit rate	2 bytes	
Current cell rate	2 bytes	
Minimum cell rate	2 bytes	
Queue length*	4 bytes	
Sequence number*	4 bytes	
Reserved	30.75 bytes	
CRC-10	10 bits	

■ **Figure 3.** Resource management (RM) cell fields.

along the path, the feedback given by the most congested link is the one that reaches the source.

Data cells also have an EFCI bit in their headers, which may be set by the network when it experiences congestion. The destination saves the EFCI state of every data cell. If the EFCI state is set when it turns around an RM cell, it uses the CI bit to give (a single bit) feedback to the source. When the source receives the RM cell from the network, it adjusts its ACR using the ER, CI, and NI values, and source parameters.

All rates (e.g., ER, CCR, and MCR) in the RM cell are represented using a special 16-bit floating point format, which allows a maximum value of 4,290,772,992 cells/s (1.8 Tb/s). During connection setup, however, rate parameters are negotiated using a 24-bit integer format, which limits their maximum value to 16,777,215 cells/s or 7.1 Gb/s.

SOURCE END SYSTEM RULES

TM4.0 specifies 13 rules that the sources have to follow. This section discusses each rule and traces the development and implications of certain important rules. In some cases the precise statement of the rule is important. Hence, the source and destination rules are quoted from the TM specification [1] in the Appendix. A list of abbreviations and their expansions is provided in the Appendix.

SOURCE RULE 1

Sources should always transmit at a rate equal to or below their computed ACR. The ACR cannot exceed PCR and need not go below MCR. Mathematically,

$$\begin{aligned} \text{MCR} &\leq \text{ACR} \leq \text{PCR} \\ \text{SourceRate} &\leq \text{ACR} \end{aligned}$$

SOURCE RULE 2

At the beginning of a connection, sources start at ICR. The first cell is always an in-rate FRM cell. This ensures that the network feedback will be received as soon as possible.

SOURCE RULE 3

At any instant, sources have three kinds of cells to send: data cells, FRM cells, and BRM cells (corresponding to the reverse flow). The relative priority of these three kinds of cells is different at different transmission opportunities.

First, the sources are required to send an FRM after every 31 cells. However, if the source rate is low, the time between RM cells will be large and network feedback will be delayed. To overcome this problem, a source is supposed to send an FRM cell if more than 100 ms has elapsed since the last FRM. This introduces another problem for low-rate sources. In some cases, at every transmission opportunity the source may find that it has exceeded 100 ms and needs to send an FRM cell. In this case, no data cells will be transmitted. To overcome this problem, an additional condition was added that there must be at least one other cell between FRMs.

An example of the operation of the above condition is shown in Fig. 4. The figure assumes a unidirectional VC (i.e., there are no BRMs to be turned around), and it has three parts. The first part of the figure shows that when the source rate is 500 cells/s, every 32nd cell is an FRM cell. The time to send 32 cells is always smaller than 100 ms. In the second part of the figure, the source rate is 50 cells/s; hence, 32 cells takes 640 ms to be transmitted. Therefore, after 100 ms an FRM is scheduled in the next transmission opportunity (or slot). The third part of the figure shows the scenario when the source rate is 5 cells/s. The intercell time itself is 200 ms.

In this case, an FRM is scheduled every third slot (i.e., the inter-FRM time is 600 ms). Since Mrm is 2, two slots between FRMs are used for data or BRM cells..

Second, a waiting BRM has priority over waiting data, given that no BRM has been sent since the last FRM. Of course, if there are no data cells to send, waiting BRMs may be sent.

Third, data cells have priority in the remaining slots.

The second and third part of this rule ensure that BRMs are not unnecessarily delayed and that all available bandwidth is not used up by the RM cells.

Figure 5 illustrates the scheduling of FRMs, BRMs, and data cells. In the first slot, an FRM is scheduled; in the next slot, assuming that a turned-around BRM is awaiting transmission, a BRM is scheduled; and in the remaining slots data is scheduled. If the rate is low, more FRMs and BRMs may be scheduled.

SOURCE RULE 4

All RM cells sent in accordance with rules 1–3 are in-rate RM cells and have their CLP bit set to 0. Additional RM cells may be sent out-of-rate and should have their CLP bit set to 1. For example, consider the third unidirectional flow of Fig. 4. It has an ACR of 5 cells/s. It is allowed to send only one in-rate RM cell every 600 ms. If necessary, it can send a limited number of out-of-rate RM cells with CLP set to 1.

The frequency of FRM is determined by parameters Nrm , Trm , and Mrm , whose default values are 32, 100 ms, and 2, respectively. During the debate on credit- vs. rate-based alternatives for traffic management [2], the rate-based group selected a default value of 32 for Nrm . This ensured that the control overhead was equivalent to that of credit-based alternative which claimed an overhead of approximately 6 percent. During normal operation 1/32th or 3 percent of all cells are FRM cells. Similarly, another 3 percent of cells are BRM cells resulting in a total overhead of 6 percent.

In practice, the choice of Nrm affects the responsiveness of the control and the computational overhead at the end systems and switches. For a connection running at 155 Mb/s the inter-RM cell time is 86.4 μ s, while it is 8.60 ms for the same connection running at 1.55 Mb/s. The inter-RM interval determines the responsiveness of the system. While most end systems and switches will do ABR computations in hardware, it has been shown that it is possible to do them in software on a Pentium™ system provided Nrm is set to 192 or higher on a 155 Mb/s link.

SOURCE RULE 5

The rate allowed to a source is valid only for approximately 500 ms. If a source does not transmit any RM cells for this duration, it cannot use its previously allocated ACR, particularly if the ACR is high. The source should resense the network state by sending an RM cell and decreasing its rate to the ICR negotiated at connection setup. If a source's ACR is already below ICR, it should stay at that lower value (and not increase it to ICR).

The timeout interval is set by the ACR decrease time factor (ADTF). This parameter can be negotiated with the network at connection setup. Its default value is 500 ms.

This simple rule was the cause of a big debate in the




Figure 4. Frequency of forward RM cells.

Forum. It is intended to solve the problem of *ACR retention*. If a source sends an RM cell when the network is not heavily loaded, the source may be granted a very high rate. The source can then retain that rate and use it when the network is highly loaded. In fact, a source may set up several VCs and use them to get an unfair advantage. To solve this problem, several so called *use it or lose it* (ULI) solutions were

proposed. Some of them relied on actions at the source; others relied on actions at the switch. The source-based solutions required sources to monitor their own rates and reduce ACR slowly if it was too high compared to the rate used.

ULI alternatives were analyzed and debated for months because they have a significant impact on the performance of the bursty traffic that forms the bulk of data traffic. The ATM Forum chose to standardize a very simple ULI policy at the source. This policy provided a simple timeout method (using ADTF as the timeout value), which reduces ACR to ICR when the timeout expires. Vendors are free to implement additional proprietary restraints at the source or switch. A few examples of such possibilities are listed in the Informative Appendix I.8 of the specification [1]; see also [4–6].

SOURCE RULE 6

If a network link is broken or becomes highly congested, the RM cells may get blocked in a queue and the source may not receive the feedback. To protect the network from continuous in-flow of traffic under such circumstances, the sources are required to reduce their rate if the network feedback is not received in a timely manner.

Normally under steady state, sources should receive one BRM for every FRM sent; under congestion, BRM cells may be delayed. If a source has sent CRM (missing RM cell count) FRM cells and has not received any BRM, it should suspect network congestion and reduce its rate by a factor of cutoff decrease factor (CDF). Here, CRM and CDF are parameters negotiated at the time of connection setup. BECN cells generated by switches (and identified by $BN = 1$) are not counted as BRM.

When rule 6 triggers once, the condition is satisfied for all successive FRM cells until a BRM is received. Thus, this rule results in a fast exponential decrease of ACR. An important side effect of this rule is that unless CRM is set high, the rule could unnecessarily trigger on a long delay path. CRM is computed from another parameter called *transient buffer exposure* (TBE) which is negotiated at connection setup. TBE determines the maximum number of cells that may suddenly appear at the switch during the first round trip before the closed-loop phase of the control takes effect. During this time, the source will have sent TBE/Nrm RM cells. Hence,

$$CRM = \left\lceil \frac{TBE}{Nrm} \right\rceil$$

The fixed part of the round-trip time (FRTT) is computed during connection setup. This is the minimum delay along the path and does not include any queuing delay. During this time, a source may send as many as $ICR \times FRTT$ cells into the network. Since this number is negotiated separately as TBE, the following relationship exists between ICR and TBE:

$$ICR \times FRTT \leq TBE \quad \text{or} \quad ICR \leq TBE/FRTT$$

The sources are required to use the ICR value computed above if it is less than the ICR negotiated with the network. In other words:

$$\text{ICR used by the source} = \text{Min}\{\text{ICR negotiated with the network, TBE/FRTT}\}$$

In negotiating TBE, the switches have to consider their buffer availability. As the name indicates, the switch may be suddenly exposed to TBE cells during the first round-trip (and also after long idle periods). For small buffers TBE should be small, and vice versa. On the other hand, TBE should also be large enough to prevent unnecessary triggering of rule 6 on long delay paths.

It has been incorrectly believed that cell loss could be avoided by simply negotiating a TBE value below the number of available buffers in the switches. Jain *et al.* [7] showed that it is possible to construct workloads where queue sizes could be unreasonably high even when TBE is very small. For example, if the FRM input rate is x times the BRM output rate (Fig. 6), where x is less than CRM, rule 6 will not trigger, but the queues in the network will keep building up at the rate of $(x - 1)$ ACR, leading to large queues. The only reliable way to protect a switch from large queues is to build it in the switch allocation algorithm. The ERICA+ algorithm [8] is one such algorithm.

Observe that the FRTT parameter, which is the sum of fixed delays on the path, is used in the formula for ICR. During the development of this rule, an estimate of RTT, including the fixed and variable delays, was being used instead of FRTT in the ICR calculation. We argued that RTT estimated at connection setup is a random quantity bearing little relation to the round-trip delays during actual operation [9]. Such parameter setting could trigger source rule 6 unnecessarily and degrade performance. Hence, the Forum decided to use the FRTT parameter instead of RTT.

Note that it is possible to disable source rule 6 by setting CDF to zero.

SOURCE RULE 7

When sending an FRM, the sources should indicate their current ACR in the CCR field of the RM cells.


SOURCE RULES 8 AND 9

Source rules 8 and 9 describe how the source should react to network feedback. The feedback consists of ER, CI, and NI bits. Normally, a source could simply change its ACR to the new ER value; but this could cause a few problems, as discussed next.

First, if the new ER is very high compared to the current ACR, switching to the new ER will cause sudden queues in the network. Therefore, the amount of increase is limited. The rate increase factor (RIF) parameter determines the maximum allowed increase in any one step. The source cannot increase its ACR by more than $\text{RIF} \times \text{PCR}$.

NI	CI	Action
0	0	$\text{ACR} \leftarrow \text{Min}(\text{ER}, \text{ACR} + \text{RIF} \times \text{PCR}, \text{PCR})$
0	1	$\text{ACR} \leftarrow \text{Min}(\text{ER}, \text{ACR} - \text{ACR} \times \text{RDF})$
1	0	$\text{ACR} \leftarrow \text{Min}(\text{ER}, \text{ACR})$
1	1	$\text{ACR} \leftarrow \text{Min}(\text{ER}, \text{ACR} - \text{ACR} \times \text{RDF})$

■ Table 2. Actions corresponding to NI and CI bit values.



■ Figure 6. Source rule 6 does not trigger if BRM flow is maintained.

Second, if there are any EFCI switches in the path, they do not change the ER field. Instead, they set EFCI bits in the cell headers. The destination monitors these bits and returns the last seen EFCI bit in the CI field of a BRM. A CI of 1 means that the network is congested and that the source should

reduce its rate. The decrease is determined by the rate decrease factor (RDF) parameter. Unlike the increase, which is additive, the decrease is multiplicative in the sense that

$$\text{ACR} \leq \text{ACR}(1 - \text{RDF})$$

It has been shown that additive increase with multiplicative decrease is sufficient to achieve fairness [10]. Other combinations such as additive increase with additive decrease, multiplicative increase with multiplicative decrease, and multiplicative increase with additive increase are unfair.

The NI bit was introduced to handle mild congestion cases. In such cases, a switch could specify an ER, but instruct that, if ACR is already below the specified ER, the source should not increase the rate. The actions corresponding to the various values of CI and NI bits are listed in Table 2.

$$\text{ACR} \leftarrow \text{Max}(\text{ACR}, \text{MCR})$$

If there are no EFCI switches in a network, setting RIF to 1 allows ACRs to increase as fast as the network directs it. This allows the available bandwidth to be used quickly. For EFCI networks, or a combination of ER and EFCI networks, RIF should be set conservatively to avoid unnecessary oscillations.

Once the ACR is updated, the subsequent cells sent from the source conform to the new ACR value. However, if the earlier ACR was very low, it is possible that the very next cell is scheduled a long time in the future. In such a situation it is advantageous to "reschedule" the next cell so that the source can take advantage of the high ACR allocation immediately [10].

SOURCE RULE 10

Sources should initialize various fields of FRM cells as follows. For virtual path connections (VPCs), the virtual circuit identifier (VCI) is set to 6. For virtual channel connections (VCCs), the VCI of the connection is used. In either case, the protocol type id (PTI) in the ATM cell header is set to 6 (110). The protocol id field in the payload of the RM cell is set to 1. The direction bit should be set to 0 (forward). The backward notification (BN) bits should be set to 0 (source generated). The ER field is initialized to the maximum rate below PCR that the source can support. The CCR is set to the current ACR. Minimum cell rate is set to the value negotiated at connection setup. Queue length, sequence number, and request/acknowledge fields are set in accordance with ITU-T Recommendation I.371 or to zero. All reserved octets are set to 6A (hex) or 01101010 (binary). This value is specified in ITU-T Recommendation I.610 (whose number coincidentally is also 6A in hex). Other reserved bits are set to 0. Note that the sources are allowed to set ER and NI fields to indicate their own congestion.

SOURCE RULE 11

The out-of-rate FRM cells generated by sources are limited to a rate below the tagged cell rate (TCR) parameter, which has a default value of 10 cells/s.

SOURCE RULE 12

The EFCI bit must be reset on every data cell sent. The alternative of congested sources being allowed to set the EFCI bit was considered but rejected due to insufficient analysis.

SOURCE RULE 13

Sources can optionally implement additional UCLI policies (see discussion of source rule 5).

DESTINATION END SYSTEM RULES

DESTINATION RULE 1

Destinations should monitor the EFCI bits on the incoming cells and store the value last seen on a data cell.

DESTINATION RULE 2

Destinations are required to turn around the forward RM cells with minimal modifications as follows. The DIR bit is set to "backward" to indicate that the cell is a BRM cell; the BN bit is set to zero to indicate that the cell was not generated by a switch; the CCR and MCR fields should not be changed. If the last cell has the EFCI bit set, the CI bit in the next BRM is set and the stored EFCI state cleared.

If the destination has internal congestion, it may reduce the ER or set the CI or NI bits just like a switch. Observe that this rule is used in the VS/VD configuration where the virtual destination is bottlenecked by the allowed rate in the next segment. In any case, the ER is never increased.

DESTINATION RULES 3 AND 4

The destination should turn the RM cells around as quickly as possible; however, an RM cell may be delayed if the reverse ACR is low. In such cases destination rules 3 and 4 specify that old out-of-date information can be discarded. The destinations are allowed a number of options for doing this. The implications of various options of destination rule 3 are discussed in Informative Appendix I.7 of the TM specification [1]. Briefly, the recommendations attempt to ensure the flow of feedback to the sources for a wide range of values for ACR of the reverse direction VC. If the reverse direction ACR is nonzero, a BRM cell will be scheduled for in-rate transmission. Transmitting BRM cells out-of-rate ensures that the feedback is sent regularly even if the reverse ACR is low or zero (e.g., in unidirectional VCs).

Note that there is no specified limit on the rate of such turned-around out-of-rate RM cells; however, the CLP bit is set to 1 in the out-of-rate cells, which allows them to be selectively dropped by the switch if congestion is experienced.

DESTINATION RULE 5

Sometimes a destination may be too congested and may want the source to reduce its rate immediately without having to wait for the next RM cell. Therefore, like a switch, the destinations are allowed to generate BECN RM cells. Also, as in the case of switch-generated BECNs, these cells may not ask a source to increase its rate (the CI bit is set). These BECN cells are limited to 10 cells/s and their CLP bits are set (i.e., they are sent out-of-rate).

DESTINATION RULE 6

An out-of-rate FRM cell may be turned around either in-rate (with CLP = 0) or out-of-rate (with CLP = 1).

SUMMARY

We have presented the source and destination rules and parameters of the ABR traffic management model. The history of and reasons behind these rules were explained. Like any other standard, these rules reflect a compromise between several different views, which we have tried to reflect. Imple-

mentation experience in the next few years will help us further understand the importance of various rules and parameters.

REFERENCES

- [1] ATM Forum, "ATM Traffic Management Specification Version 4.0," Apr. 1996. Available through <ftp://ftp.atmforum.com/pub/approved-specs/af-tm-0056.000.ps>
- [2] R. Jain, "Congestion Control and Traffic Management in ATM Networks: Recent Advances and a Survey," *Comp. Networks and ISDN Sys.*, Oct. 1996; also ATM Forum/95-0177, Feb. 1995.
- [3] R. Jain, K. Ramakrishnan, and D. Chiu, "Congestion Avoidance in Computer Networks with a Connectionless Network Layer," DEC-TR-506, reprinted in C. Partridge, Ed., *Innovations in Internetworking*, Artech House, Oct. 1988.
- [4] K. K. Ramakrishnan, P. P. Mishra, and K. W. Fendick, "Examination of Alternative Mechanisms for Use-it-or-Lose-it," ATM Forum/95-1599, Dec. 1995.
- [5] A. W. Barnhart, "Evaluation and Proposed Solutions for Source Behavior #5," ATM Forum/95-1614, Dec. 1995.
- [6] R. Jain et al., "A Fix for Source End System Rule 5," ATM Forum/95-1660, Dec. 1995.
- [7] R. Jain et al., "More Straw-Vote Comments: TBE vs Queue Sizes," ATM Forum/95-1661, Dec. 1995.
- [8] R. Jain et al., "ERICA Switch Algorithm: A Complete Description," ATM Forum/96-1172, Aug. 1996.
- [9] R. Jain et al., "Straw-Vote Comments on TM 4.0 R8," ATM Forum/95-1343, Oct. 1995.
- [10] D. Chiu and R. Jain, "Analysis of the Increase/Decrease Algorithms for Congestion Avoidance in Computer Networks," *Comp. Networks and ISDN Sys.*, vol. 17, no. 1, June 1989, pp. 1-14.
- [11] R. Jain et al., "Out-of-Rate RM Cell Issues and Effect of Trm, TOF, and TCR," ATM Forum/95-973R1, Aug. 1995.

BIOGRAPHIES

RAJ JAIN [F] is a professor of computer information sciences at The Ohio State University in Columbus, Ohio. Prior to joining the university in April 1994, he was a senior consulting engineer at Digital Equipment Corporation, Littleton, Massachusetts, where he was involved in the design and analysis of many computer systems and networks including VAX clusters, Ethernet, DECnet, OSI, FDDI, and ATM networks. Currently he is very active in the Traffic Management working group of the ATM Forum and has influenced its direction considerably. Raj Jain received a Ph.D. degree in computer science from Harvard University in 1978. He taught at the Massachusetts Institute of Technology in 1984, 1985, and 1987. He is the author of two books, *The Art of Computer Systems Performance Analysis* and *FDDI Handbook: High-Speed Networking with Fiber and Other Media*.

SHIVKUMAR KALYANARAMAN [StM] is a doctoral candidate in computer sciences at The Ohio State University. He received his B.Tech degree from the Indian Institute of Technology, Madras, India, in July 1993. He received his M.S. degree from The Ohio State University in 1994. His research interests include broadband networks, transport protocols, congestion control, distributed systems, and performance analysis. He is a co-inventor of two patents, and has co-authored several articles and ATM Forum contributions in the field of ATM congestion control.

SONIA FAHMY [StM] received her B.S. degree from American University in Cairo, Egypt, in June 1992, and her M.S. degree from The Ohio State University in March 1996, both in computer science. She is currently a Ph.D. student at The Ohio State University. Her main research interests are in the areas of broadband networks, congestion control, performance analysis, distributed computing, and programming languages. She has co-authored several papers and ATM Forum contributions.

ROHIT GOYAL is a Ph.D. student with the Department of Computer and Information Science at The Ohio State University, Columbus. He received his B.S. in computer science from Denison University, Granville, Ohio. His work has been published in several ATM Forum contributions and technical reports. His other interests include distributed systems, artificial intelligence, and performance analysis.

SEONG-CHEOL KIM received his Ph.D. from Polytechnic University in 1995 in electrical engineering. Since 1995 he has been with Samsung Electronics as a principal engineer. His research interests include traffic control, congestion control, and multimedia and ATM communications.

¹ All our papers and ATM Forum contributions are available at <http://www.cis.ohio-state.edu/~jain/>