



15




16



17

	oened? asn't long iin: 3-bit h												
State/prediction	BHR=NNN	<b>N</b> *	Т	Т	Т	Т	Т	Т	Т	Т	Т	Т	Т
	BHR=NNT	Ν	N*	Т	Т	Т	Т	Т	Т	Т	Т	Т	т
	BHR=NTN	Ν	Ν	Ν	Ν	N	Ν	Ν	Ν	Ν	Ν	Ν	Ν
"active pattern"	BHR=NTT	Ν	Ν	<b>N</b> *	Т	Т	Т	т	Т	Т	Т	т	Т
	BHR=TNN	Ν	Ν	Ν	Ν	N	Ν	Ν	Ν	Ν	Ν	Ν	Ν
	BHR=TNT	Ν	Ν	Ν	Ν	N	<b>N</b> *	Т	Т	Т	т	Т	Т
	BHR=TTN	Ν	Ν	Ν	Ν	N*	Т	Т	Т	Т	Т	Т	Т
	BHR=TTT	Ν	Ν	Ν	Ν	N	Ν	Ν	Ν	Ν	Ν	Ν	Ν
Outcome	NNN	Т	Т	Т	Ν	Т	Т	Т	Ν	Т	Т	Т	Ν


18




- Design choice I: one global BHR or one per PC (local)?
   Each one captures different kinds of patterns
   Global is better, captures local patterns for tight loop branches
- Design choice II: how many history bits (BHR size)?
  - Tricky one
  - + Given unlimited resources, longer BHRs are better, but...


**Correlated Predictor** 

- PHT utilization decreases
  - Many history patterns are never seen
  - Many branches are history independent (don't care)
    PC xor BHR allows multiple PCs to dynamically share PHT
  - PC xor BHR allows multiple PCs to dynamically share PHT
     BHR length < log<sub>2</sub>(PHT size)
- внк length < log<sub>2</sub>(PHT size)
   Predictor takes longer to train
- Typical length: 8–12





22



Why Does a BTB Work?

• Target encoded in insn itself  $\rightarrow$  same "taken" target every

Target held in a register → can be different each time
Indirect conditional jumps are not widely supported

+ Dynamically linked functions (DLLs): target always the same

· Dynamically dispatched (virtual) functions: hard but uncommon

· Because most control insns use direct targets

· Also two indirect unconditional jump idioms

- Function returns: hard and common but...


· Switches: hard but uncommon

23

time


• What about indirect targets?


· Two indirect call idioms




Branch Target Buffer (continued)

• At Fetch, how does insn know it's a branch & should read BTB?







Branch Prediction Performance
Dynamic branch prediction

20% of instruction branches
Simple predictor: branches predicted with 75% accuracy
CPI = 1 + (20% × 25% × 2) = 1.1

More advanced predictor: 95% accuracy

CPI = 1 + (20% × 5% × 2) = 1.02

Branch mis-predictions still a big problem though

Pipelines are long: typical penalty is 10+ cycles
Pipelines are superscalar (later)

